


FMT1750

Classic Bumpermate

PARTS DIAGRAM



Fast Mover Tools

T: 01582 661993 F: 01582 667100 E: sales@fastmovertoolsuk.com

FMT1750

Classic Bumpermate



PARTS LIST

FMT1450/4	1	Base	
FMT125/1	1	Main Upright	
FMT125/2	1	Top Piece	
FMT1450/3	2	Base Leg	
FMT1650/5	4	Bumper Clamp	
FMT1650/1	2	Clamp Holder	
FMT133	2	200mm Wheel	
FMT256	4	Bar Lock Holder	
FMT1650/3	2	Top Piece	
PARTS BAG	1		
Containing -	1	FMT1254/3	Steel Pin
	1	FMT1254/4	Swivel Bar
	2	M12SW	M12 Spring Washer
	4	M10X40	M10 x 40 Set Screw
	1	FMT131/1	T-piece
	1	FMT131/2	Eyebolt
	2	M12X80	M12 x 80 Set Screw
	8	M10WS	M10 Washer
	4	M10N	M10 Nyloc
	9	FMT132	Finger Screw

FMT1750

Classic Bumpermate

PARTS LIST

