



**FAST
MOVER**
Automotive Refinishing

FMT7560 Dent Tool Kit

Product Instruction Manual



Read the operating manual thoroughly before work and keep it for future reference.

T: +44 (0)1582 661993

F: +44 (0)1582 667100

E: sales@fastmovertoolsuk.com



INCLUDES:

- 1pc glue gun (220-240V~, 50Hz, 40W)
- 1pc sliding hammer to pull out hard dents
- 1pc dent lifter (Baby face mini lifter or normal mini lifter) for slight dents on flat surface
- 1pc glue remover
- 1pc scraper for gentle removal of dent pads
- 8pcs black glue sticks (11 x 200mm) with very good performance for best results
- 19pcs glue tabs in various sizes and shapes

OPERATION AND USE OF DENT TOOL KIT

Step 1:

Identifying the vehicle collision /dent. Clean the surface of the paintwork. Use only mild cleaning agents. The use of a surface coarse sponge will cause irreparable damage.

Step 2:

Use the glue gun, push the glue stick into the back of the glue gun. Heating the glue gun causes the glue stick to melt.



Step 3:

Use the hot glue gun, put glue on the glue tab, and then place the recess in the dent glue tab.



Step 4:

Use the T bar slide hammer or dent mini lifter extraction of the bump. What tool you use, also depends on the size of the dent; Up to 30mm diameter use the dent mini lifter, if larger then use the slide hammer



Fast Mover Tools Limited

T: 01582 661993 F: 01582 667100 E: sales@fastmovertoolsuk.com
W: www.fastmovertoolsuk.com





Step 5:

When the temperature reaches the correct time, do not use too much force. Pull until the glue tab is removed.



Step 6:

Use the release agent to dissolve glue. Use the scraper to remove the glue.



Step 7:

Finally, using a soft clean cloth wipe away any residual glue, restoring the paintwork to the original condition.



Fast Mover Tools Limited

T: 01582 661993 F: 01582 667100 E: sales@fastmovertoolsuk.com
W: www.fastmovertoolsuk.com





ELECTRICAL INFORMATION

Warning

Mains plug replacement (UK & Ireland only)

If you need to replace the fitted plug of the tool, then follow the instructions below.

Machines that are connected direct to mains supply.


Machines that are double insulated do not require a cord grip.

If in doubt consult a qualified electrician.

The wires are coloured as follows:

Blue **Neutral (N)**

Brown **Live (L)**



3 amp BS 1363A Fuse

Always secure the wires in the plug terminals carefully to make sure that no loose strands are left exposed as they can short circuit and cause injury, fire and/or damage the tool.

Secure the cable in the cord grip firmly.

Never use a light socket. Never connect the live (L) or neutral (N) wires to the earth pin marked (E).

NOTE: If your mains wires differ from the above consult a qualified electrician. Always make sure the mains supply is of the correct voltage and that you use the correct fuse protection.

Regularly inspect all machines, electrical connections and wiring condition for damage. Any faults detected should be immediately rectified before further use of the machine. Always have the wiring checked by a qualified electrician.

In use ensure all wiring and extension cords are kept clear of any cutting tools, sharp objects and any other workshop hazards such as wet floors, chemicals, solvents etc.

This machine is protected by a 3 amp fuse make sure the correct fuse is used.

To prevent fire or shock hazards do not expose these products to rain or moisture.

Fast Mover Tools Limited

T: 01582 661993 F: 01582 667100 E: sales@fastmovertoolsuk.com
W: www.fastmovertoolsuk.com





Fast Mover Tools Limited

T: 01582 661993 F: 01582 667100 E: sales@fastmovertoolsuk.com
W: www.fastmovertoolsuk.com





Warranty

We hope that you will be very happy with your purchase. If you do have a problem with your tool, you have the added peace of mind of a 12 month warranty, which comes into date from the date of purchase (proof of purchase required).

Scope of Warranty

- The warranty will cover you from all faults caused by defective components or poor workmanship.
- Tools sent outside the EU are not covered by this warranty.
- Product must be returned to us, the warranty does not cover cost of carriage.
- If the product is no longer in manufacture, it will be replaced with a tool of equivalent or higher specification.

What is not covered

- Normal wear and tear caused by use in accordance with the operating instructions.
- Accidental damage, faults caused by negligent use or care, neglect, misuse or careless operation, handling and storage of the product.
- Modification of, or change of, any part of this product in any way.
- Faults caused by use of non compatible accessories.
- Faults caused by incorrect installation.
- Repairs or alterations carried out by non-approved parties.

Validity

- This warranty is valid for 12 months after date of purchase.
- Warranty is rendered invalid if;
 - Tool is taken apart for any reason without our consent.
 - Tool is not maintained daily.
 - Air supply line is not used with a properly working air filter.



**Please look after the environment, dispose of all packaging in a responsible way.
Always dispose of tools in accordance with local authority guidelines.**

© 2015 Fast Mover Tools Ltd. This document is copyright and is not to be copied, circulated, distributed or shown to anyone other than the intended recipient without the express permission of the directors.

Fast Mover Tools Limited

T: 01582 661993 F: 01582 667100 E: sales@fastmovertoolsuk.com
W: www.fastmovertoolsuk.com

